

imation



IMATION SECURE SCAN



Quick Start Guide

1

Unpacking your Imation Secure Scan



The following items are contained inside the case:

1 Imation Secure Scan

2 2 USB Cables

3 Resource CD

4 Quick Start



2

Installing the Software on a PC

Minimum System Requirements:


- Microsoft® Windows® 2000, XP, Vista operating system (32-bit)
 - Pentium 4 Processor
 - 512MB RAM memory
 - 10MB of Hard Disk Space available
- Two Available USB-2 Ports (two are necessary for power and data transfer requirements)
 - Color Monitor with 1024 x 768 or greater native screen resolution
1. **Do not** connect the Imation Secure Scan to a host computer before installing the software.
 2. Close all unnecessary applications on the host computer.
 3. Insert the Imation Secure Scan **Resource CD** in the CD-ROM drive. Installation routine begins in auto-play systems; if not, click on **My Computer**, browse to CD drive, and double-click **setup**.

Note: Some corporate firewalls may display a precautionary screen. Click **OK** to proceed. The latest software installation, including Windows 7 (64 bit) version, can also be down-loaded from:


www.imation.com/support

When basic installation is complete, the installation wizard installs the device drivers and displays the following sequence of screens.

Complete Hardware Installation (step 3) before launching software.



Welcome Wizard screen



Completing Driver Installation



Successful Installation




3

Hardware Installation


1. Connect both the **USB cables** to two available USB ports on the host computer.
2. Select **No, not at this time** when Found New Hardware Wizard offers to search the internet for software. Click **Next**.
3. Select **Install from a list or specific location** and click **Next**.
4. Select **Search for best driver in these locations** and browse to **C:\ProgramFiles\Imation Secure Scan\Baltech**. Click **Next**. Repeat installation if prompted.
5. Click **Continue Anyway** when the Microsoft logo notice appears. Click **Finish** to close the Wizard once the Found New Hardware Wizard is finished.

If the software and hardware are installed correctly, the CM Reader and Barcode Scanner each appear within a green port identification box in the program status section on the main software screen. (The actual port numbers may vary depending on other peripherals attached to the host computer.)

Correct installation



Device not recognized




If the identification box is red, the computer does not recognize the device. Unplug the USB cables from the computer, reboot, and follow Step 2 again to install the drivers.


4

Using your Imation Secure Scan

The Quick Start Guide covers only the most basic steps in the operation of the **Imation Secure Scan** and its features. To get the maximum use of this device and full benefit of all of its functions, consult the detailed User Manual available on the Resource CD or under the “Help” tab from the main software screen.

OPEN the software program from desktop icon  or START menu. Note: For computer systems without physical serial communications ports, a delay of up to a

Secure Scan Program Screen




minute or more may occur during program start-up. A customization box will appear for your name and location entries which will appear on main menu screen. (A)

If the two COM port identification boxes are green, the software is correctly installed. Scanning can proceed in the following order:

1. Select the type of scan session in the Session Box. (B)
2. Initiate scanning by clicking on Start Session. (C) Indicator changes to “Session Active”
3. Place an LTO cartridge on the scanner with the barcode placed against the window and the Ultrium logo up. **The cartridge can remain in its protective case during the scanning session.**
4. The status bar (D) displays the scanning progress as the cartridge memory chip is read. The program status box above the bar indicates the completion of a scan.


Good Cartridge Scan

Unlocked cartridge



Locked Cartridge

Locked cartridge



- The health of the cartridge is displayed in the cartridge status section **E** as well as its lock status (see above). Imation Secure Scan records the Volser number **F** along with the memory chip information for possible evaluation by Imation Technical Service. Consult the User Manual for more details about these features and an explanation of the health disposition messages that display.
- The scan results table **G** shows the results of the last 20 cartridges scanned. The table summarizes the results of the scan including scan date, Volser, cartridge serial number, date of manufacturer, manufacturer of cart, drive mounts, gigabytes written and read since new, along with the cart status.


Scan Results Table with Data

Scan Date	Volser	Cart SN	Date/Mfg	Cart Mfg	Mounts	GB Wrt	GB Rd	Status
03/10/2011	004744L3	0D55169950	6/4/2010	IMATION	17	1994	4	Good Cartridge
03/10/2011	V05599L3	0D36219660	10/1/2009	IMATION	1	525	0	Good Cartridge
03/10/2011	005166L3	0D68536990	10/21/2010	IMATION	7	522	1	Good Cartridge
03/10/2011	000023L4	0947307260	4/8/2009	FUJIFILM	11	44	1	Good Cartridge


- The Windows Tool Bar at the upper left corner of the program screen offers four options when the **File** tab is clicked:

- Library Summary screen with options for -
 - Selecting the data records shown on the Cartridge Summary page
 - Displaying age, usage, mount, and drives of interest graphs
 - Sorting cartridge generations (LTO1, LTO2 . . .) in the display

Summary Page



Cartridge Age Graph



Volser Summary Table

Scan Date	Volser	Cart SN	Mounts	GB Wrt	GB Rd	Last Drive	Status
01/20/2009	0C66836270	6	26	0	0	HU10520GUR	
01/20/2009	0C66836270	9	26	0	0	HU105211VC	
01/20/2009	0C66836270	8	104	0	0	HU105211VC	
01/20/2009	0C66836270	9	104	0	0	HU105211VC	
01/20/2009	0C66836270	6	26	0	0	HU105211VC	
01/20/2009	0C66836270	7	26	0	0	HU105211VC	
01/20/2009	0C66836270	8	104	0	0	HU105211VC	
01/20/2009	0C66836270	9	104	0	0	HU105211VC	
01/20/2009	0C66836270	6	26	0	0	HU105211VC	
01/20/2009	0C66836270	8	104	0	0	HU105211VC	
01/20/2009	0C66836270	9	104	0	0	HU105211VC	
01/20/2009	0C66836270	6	26	0	0	HU105211VC	
01/20/2009	0C66836270	8	104	0	0	HU105211VC	
01/20/2009	0C66836270	9	104	0	0	HU105211VC	
01/20/2009	0C66836270	6	26	0	0	HU105211VC	
01/20/2009	0C66836270	8	104	0	0	HU105211VC	
01/20/2009	0C66836270	9	104	0	0	HU105211VC	
01/20/2009	0C66836270	6	26	0	0	HU105211VC	
01/20/2009	0C66836270	8	104	0	0	HU105211VC	
01/20/2009	0C66836270	9	104	0	0	HU105211VC	

- Volser Summary table displaying scan history of a particular cartridge
- Upload to Imation to upload usage records only (no information stored on the cartridge itself is even read!) to Imation for in-depth analysis by Imation Technical Service. Users can add other email addresses or generate files for a manual email send if there are overlying security issues or other concerns.
- Exit.

Technical assistance for Imation Secure Scan may be obtained by calling Imation Technical Support at **1-800-351-8186** and select option 1.

LIMITED WARRANTY AND LIMITATION OF REMEDIES: Imation warrants that this product is free from defects in material and manufacture at the time of purchase. If any such defect appears within 1 year, Imation's entire liability is, at Imation's option, either (a) repair, or (b) replacement of the product, or (c) refund of the purchase price of the product, which must be returned to Imation with proof of purchase. This warranty does not apply to product failure resulting from misuse, abuse, accident, neglect or mishandling, improperly adjusted or maintained drives, incorrect environments or wear from ordinary use. IMATION SHALL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL LOSS OR DAMAGE (INCLUDING WITHOUT LIMITATION DAMAGES FOR LOSS OF PROFITS, SAVINGS OR DATA) IN ANY WAY RELATED TO THE PRODUCT. This does not preclude claims for personal injury. Some states or countries do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or country to country.

.....

FCC ID: PB4ISS-LTOA (for Ver. 1, SN beginning with A001)
Contains FCC ID: OKY1003925351A02C (for Ver. 2, SN beginning with A101)
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Modifying this device may void the user's authority to operate the device.

Canada:
IC: 6900A-ISS LTOA (for Ver. 1, SN beginning with A001)
Contains IC: 7657A-10039253 (for Ver. 2, SN beginning with A101)
The term "IC:" before the equipment certification number only signifies that the Industry Canada technical specifications were met.

Thailand: This telecommunication equipment conforms to NTC technical requirement.

Singapore: Complies with IDA Standards, Dealer's License No. DA104910

Indonesia: Certificate No. 13623, PLG. ID: 3157

Philippines: NTC Type Approval No: ESD-1004468C

Product Safety
Conforms to UL Std 60950-1
Certified to CAN/CSA Std C22.2 No. 60950-1

Laser Safety
CLASS 1 LASER PRODUCT
As tested to IEC 60825-1, 2007 and 21CFR1040.10

CAUTION: Class 2 laser radiation when open. Do not stare into the beam.
AVERTISSEMENT: Rayonnement laser de catégorie 2 lorsque l'appareil est allumé. Éviter de regarder le faisceau lumineux.
Caution - Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Imation Enterprises Corp.
1 Imation Way
Oakdale, MN 55128-3414 U.S.A

www.imation.com

Imation and the Imation logo are trademarks of Imation Corp. All other trademarks are the property of their respective owners.
66950973-B